

Determination of the mechanical properties at elevated temperature for a PP homopolymer applying tensile tests and DMA measurements

Josef F. PUEHRINGER^{1*}), Christian MAIER², Gernot ZITZENBACHER²

¹⁾ Upper Austria University of Applied Sciences, Research and Development Ltd.,
Stelzhamerstrasse 23, 4600 Wels, Austria

²⁾ Upper Austria University of Applied Sciences, School of Engineering and
Environmental Sciences, Stelzhamerstrasse 23, 4600 Wels, Austria

*) josef.puehringer@fh-wels.at

The thermoforming process can be split into the following steps: heating of the semi-finished product (film or plate), prestretching, forming, cooling and demoulding. The plate is heated up to a temperature, where the material is in the rubber elastic state. Thus the determination of temperature dependent mechanical properties is essential for the choice of the *forming window* in the thermoforming process¹.

In this work the mechanical properties of a polypropylene homopolymer² were investigated by two methods. Stress-strain-curves were recorded for temperatures ranging from room temperature to a temperature near the melting point (160 °C) by a hot tensile test³. The curves were evaluated and characterised by the tensile moduli and tensile strengths. The material was also tested by dynamic mechanical analysis (DMA)^{4,5} in the three-point bending mode at 1 Hz. The sample temperature was raised from -50 °C to 160 °C. The absolute value of the measured dynamic flexural modulus was set in relation to the static tensile modulus (fig. 1) and the tensile strength.

The values of these moduli showed a nearly linear correlation at all temperatures except 160 °C. So DMA measurements could be a quite time saving and powerful tool for mechanical material characterisation because it also allows the analysis the visco-elastic properties by analysis of the relaxation spectrum.




Figure 1: Comparison of the tensile moduli at elevated temperature with the flexural moduli got from DMA-measurements dependent on temperature at a frequency of 1 Hz.

References

1. J. L. Throne, Understanding Thermoforming, Carl Hanser Verlag, Munich, 2nd ed., 2008, ISBN 978-3-446-40796-1, p. 133.137.
2. J. F. Puehringer, The Rheology of Crystallisation, Ph.D. Thesis at the Johannes Kepler University, Linz, work in progress, chapter 3.
3. J. L. Throne, Technology of THERMOFORMING, Hanser/Gardner Publications, Cincinnati, 1996, ISBN 1-446-17812-0, p. 212.213,
4. H. P. Menard, Dynamic mechanical Analysis, CRC Press, Boca Raton – London – New York, 2nd ed., 2008, ISBN 978-1-42005312-8, p. 71-93.
5. R. P. Chartoff, J. D. Menczel, S. H. Dillmann, Dynamic mechanical analysis (DMA) in: J.D. Menczel, R. B. Prime, THERMAL ANALYSIS OF POLYMERS – Fundamentals and Applications, John Wiley & Sons, Inc., Publication, Hoboken, 2009, ISBN 978-0-471-76917-0, p. 387-495.

Acknowledgements: Financial support for this work was provided by the Local Government of Upper Austria within the framework of the funding programme “Kunststoffstandort Oberösterreich”. We would also like to thank the Transfer Center Kunststoff Technik (TCKT) in Wels for providing the equipment for performing the tensile tests at elevated temperature.